



LOCATE Z CLIPS ON WALL AND SECURE WITH SCREWS APPROPRIATE FOR WALL SUBSTRATE.

KSP  
INSTALLATION INSTRUCTIONS

USING APPROPRIATE SCREWS,  
ATTACH THE Z-CLIP TO THE WALL

1. POSITION KSP WALL PANEL ONTO Z-CLIP
2. ATTACH BOTTOM ANGLES

