



**STRUCTURAL NOTE:**  
STRUCTURAL SLAB F- NUMBERS  
F<sub>r</sub> - FLOOR FLATNESS NUMBER  
SPECIFIED OVERALL VALUE = 38  
MINIMUM LOCAL VALUE = 25

**LIFTING NOTES:**  
CONCRETE MUST CURE TO DESIGN STRENGTH. AFTER CURING, RAISE SLAB BY CAREFULLY DRIVING LIFTING SCREWS. DRIVE EACH SCREW 2 OR 3 TURNS (MAX) IN SEQUENCE UNTIL DESIGN OPERATING HEIGHT HAS BEEN REACHED. DO NOT DRIVE INDIVIDUAL SCREWS MORE THAN 2 OR 3 TURNS, OR TURN THEM OUT OF SEQUENCE. DOING SO MAY CAUSE DAMAGE TO CONCRETE OR ISOLATOR.  
*TURNING IN EXCESS OF 2 TO 3 TURNS MUST BE APPROVED BY STRUCTURAL (CONCRETE) ENGINEER.*

DIMENSION FORMAT: IN (mm)

SCALE: NTS



LSM ISOLATED SLAB:  
INSTALLATION SEQUENCE

Revised  
12/07/2017

Drawing No.  
AA001786

[kineticsnoise.com/lsm](http://kineticsnoise.com/lsm)